



ISTRUZIONI PER EROGAZIONE CORRENTE ELETTRICA
INSTRUCTIONS FOR ELECTRICITY SUPPLY

INSERIRE IL CREDITO E ATTIVARE L'EROGAZIONE DELLA CORRENTE PREMENDO IL TASTO CORRISPONDENTE ALLE PRESA DEL POSTO OCCUPATO DAL CAMPER.

OGNI PRESSIONE CORRISPONDE A 4 ORE DI EROGAZIONE, PER AVERE PIU' ORE CONSECUTIVE (4h, 8h, 12h), PREMERE PIU' VOLTE.

Es. 1€ + 1 PRESSIONE = 4 ORE DI EROGAZIONE
2€ + 2 PRESSIONI = 8 ORE DI EROGAZIONE

IL CREDITO INSERITO VALE SOLO PER UNA PRESA DI CORRENTE, NON SI PUO' DIVIDERE IL CREDITO INSERITO SU ALLACCI DIVERSI.

NON EROGA RESTO.

ENTER THE COIN AND PRESS THE CORRESPONDING KEY TO START THE ELECTRICITY SUPPLY FOR YOUR CAMPERVAN.

EVERY TIME YOU PRESS A BUTTON YOU ARE ENTITLED TO 4 HOURS OF DISPENSING, TO HAVE MORE CONSECUTIVE HOURS (4H, 8H, 12H), TAP A BUTTON SEVERAL TIMES.

E.G. : 1€ + ONE TAP A KEY = 4 HOURS ELECTRICITY
2€ + TWO TAP A KEY = 8 HOURS ELECTRICITY

THE CREDIT ENTERED APPLIES ONLY TO A POWER OUTLET, YOU CAN NOT DIVIDE THE CREDIT ENTERED ON DIFFERENT CONNECTIONS.

THIS DEVICE DOES NOT GIVE THE REST